

Thank you for your purchase and instructions on how to use the Nisetro Capture.

Thank you for purchasing the Nisetro Capture kit. I'm in charge of the support, Katsukity.

The installation of the driver is not automatic. You need to install it manually.

Please download the driver and viewer software from the following URL.

<http://katsukity.co.jp/new3dsview.zip> (Windows for new 3DS/XL)

http://katsukity.co.jp/new3dsview_mac.zip (Mac for the new 3DS/XL/LL)

http://katsukity.co.jp/new3dsview_rpi.zip (Raspberry Pi for the new 3DS/XL)

Please be careful when plugging and unplugging the mini USB cable. If strong pressure is applied on the USB slot while the cable is connected, the capture card may not be recognized. If the capture card has issues, please ask us to repair it. If you attempt to disassemble the kit, you will void your warranty.



偽トロキャプチャ
Nisetro capture

Please input the product key when the viewer software runs:

Your product key you will find at your invoice ☺

[1. How to install the driver]

Please unzip the zip file and the installer under the driver folder.

If your operating system is 32bit, please run the "install_32bit.exe" under the driver folder.

If your operating system is 64bit, please run the "install_64bit.exe" under the driver folder.

The driver will be installed, then please run the viewer software and input a product key.

[2. How to capture]

Please run the "n3DS_view.exe."

If necessary libraries are missing, please install both C++ and DirectX runtime libraries from the following URLs.

<http://www.microsoft.com/en-US/download/details.aspx?id=30679>

<http://www.microsoft.com/en-US/download/details.aspx?id=35>

If the lower display is distorted, Please adjust values between 14 and 12 from Config > Calibration > Lower screen CLOCK: on the viewer software.

For audio, please connect the headphone terminal on the Nintendo 3DS to the line-in connector on your PC using a mini USB cable. If sound noise bothers you, please use a ground connection for the PC power plug, use resistance wire between the 3DS and the PC. A live broadcast set is also available. Please contact us.

[3. If the viewer doesn't run]

Please unplug all other USB devices from your computer.

Please connect directly to the PC without connecting through a USB hub or other device.

The USB port placed on the front of your desktop may not recognize the capture board if it is a part of a built-in hub. Please plug in your capture board using the USB port on the rear of the machine.

If the driver is falsely recognized as another device, select "Show hidden devices" on Device Manager and delete any incorrect hardware.

[5. If you cannot install the driver]

If you really need help, please contact my Skype (capture_support).

We will help you remotely.

We offer free support only at the time of purchase. If you re-install the driver and the viewer software on a brand new OS or after a clean up, it may take longer to install the driver.

Katy's Game Direct Shop
<http://3dsgamecapture.com/>
© All right reserved by Katy Co. Ltd.